

**City of Dixon – Building Department
Street Opening (Right of Way) Permit Holder Responsibilities**

1. Protect area of excavation with ample barricades, fences, etc.
2. Backfill compacted properly.
3. Saw street surface 1 foot wider than trench.
4. If existing street is bituminous, backfill to depth of 10”, place 8” of concrete in excavation and 2” of hot mix over concrete. If existing street is concrete or brick, backfill to an 8” depth. Pour and finish 8” concrete slab to meet existing surface.
5. Clean area of excess fill, etc.

NOTE: Per City Code Section 3-2-10, Concrete with a double layer of five (5) mil poly (minimum) separation may be used to surface the trench only as a temporary measure when hot mix material is not available. Within thirty (30) days of hot mix material being available, the concrete shall be removed and replaced by hot mix.